

MERCURY IGNITION SYSTEM

Q & A FOR THE MERCURY IGNITION SYSTEMS

■ WHAT ARE THE DIMENSIONS OF THE MERCURY FACEPLATE?

8" W x 4" H

■ WHAT PROTECTION FROM WATER DOES THE MERCURY OFFER?

The pilot hood is expertly designed to provide enhanced protection by directing water away from the pilot components. When the WATERSTOP™ fitting is incorporated on the burner, there is unparalleled protection for the system from water and debris.

■ CAN THE MERCURY BE INSTALLED IN THE FIELD?

The Mercury can easily be installed on-site, to a new or existing burner system. Our comprehensive manual provides detailed installation instructions.

■ DOES THE MERCURY REQUIRE A KEY VALVE?

The Mercury uses a manual controlled gas valve that uses a control knob for turning on, lighting, controlling the flame height, and turning the system off. The control knob is used rather than a key and key valve. A key valve can be added for a redundant shut-off but is not required.

■ WHAT IS THE MERCURY'S WARRANTY?

The ignition is backed by a 3 year warranty on residential installations and a 1 year warranty on commercial installations.

