

## MERCURY IGNITION SYSTEM

### Q & A FOR THE MERCURY IGNITION SYSTEMS

---

#### ■ WHAT ARE THE DIMENSIONS OF THE MERCURY FACEPLATE?

8" W x 4" H

#### ■ WHAT PROTECTION FROM WATER DOES THE MERCURY OFFER?

*The pilot hood is expertly designed to provide enhanced protection by directing water away from the pilot components. When the WATERSTOP® fitting is incorporated on the burner, there is unparalleled protection for the system from water and debris.*

#### ■ CAN THE MERCURY BE INSTALLED IN THE FIELD?

*The Mercury can easily be installed on-site, to a new or existing burner system. Our comprehensive manual provides detailed installation instructions.*

#### ■ DOES THE MERCURY REQUIRE A KEY VALVE?

*The Mercury uses a manual controlled gas valve that uses a control knob for turning on, lighting, controlling the flame height, and turning the system off. The control knob is used rather than a key and key valve. A key valve can be added for a redundant shut-off but is not required.*

#### ■ WHAT IS THE MERCURY'S WARRANTY?

*The ignition is backed by a 3 year warranty on residential installations and a 1 year warranty on commercial installations.*



Visit us online at [Warming-Trends.com](http://Warming-Trends.com) for more information and pricing or call **303-346-2224** to speak with one of our Flame Specialists today.

VISIT US ONLINE  
TO LEARN MORE